

**Job Remarks (no cost)**

Well: Fcu 7137

Wellbore: Fcu 7137

**Well Information**

Well Name	Regulatory Well Name	Field Name	Lease
Fcu 7137	Fullerton Clearfork Unit 7137	Fullerton Unit	Fullerton Clearfork Unit

**Job Information**

Primary Job Type	Job Subcategory	Job Category	Orig WCI	WRC	WPC
Workover PI	Recomplete Higher	Recompletion	1.9	Higher	Work Aid (WA)

**Summary of Daily Operations**

Report Number	Rpt Start Dt/Tm	Mgmt Summary	Remarks
1	7/19/2011	backhoe cleared brush and levelled location.	
2	8/17/2011	MIRU	
3	8/18/2011	UNhang well and unset pump and then circulate well w/200 bbls of BW POOH w/rods secure well and SDFN.	
4	8/19/2011	ND WH NU BOP then POOH w/prod. tbg then LD bottom section and BHA RIH killstring SDFN.	
5	8/22/2011	POOH w/killstring and then PU CIBP mix 2 sks cement then RIH to 6,136' set CIBP then test to 500 then POOH SDFN.	
6	8/23/2011	POOH w/killstring and ND BOP then ND WH NU Cameron WH NU BOP RIH w/killstring SDFN.	
7	8/24/2011	POOH killstring RU WL RIH CBL then perf. 6030'-6039' then POOH WL RU all 3 1/2 equipment PU PKR RIH w/20 jts 3 1/2 SDFN.	
8	8/25/2011	RIH w/tbg unload frac stack set PKR at 5,933 then ND BOP begin to NU WH SDFN.	
9	8/26/2011	TIE BACK NU WH Frac STACK PUMP 6 BBLS OF ACID RU PU move to FCU 2247 SDFN.	
10	8/27/2011	MI RU Halliburton to frac well and then SDFN. Continue to flow well back.	
11	9/8/2011	MIRU Pulling unit secure well and SDFN.	
12	9/9/2011	Bled down SIP. Flow back well.	
13	9/12/2011	Bled well down ND Frac Stack changed wellhead NU BOP tested to 500 psi unset pkr POOH LD 20 jts SDFN.	
14	9/13/2011	POOH LD tbg ND BOP ND WH change out tbg then U BOP RIH w/ 2 7/8 SDFN.	
15	9/14/2011	Continue to RIH w/ 2 7/8tbg landed on bottom then ND BOP NU WH SDFN.	
16	9/15/2011	Did rig inspection PU pump and rods RIH SDFN.	
17	9/16/2011	PU rest of rods load and test then respace pump then hang well on RD clean up location SDFN.	
18	9/27/2011	MIRU, Circulate, Re-space (Remove 1" x 4' Sub)	
19	9/28/2011	Check pump action, RD & Clean location	